

### REMOVING THE DOOR

1. Open door. Lift the rod and remove door from hinge. **(A)**
2. Remove bottom floor panel. **(B)**
3. Pinch back of the door hinge block with pliers, on the upper and lower sections. Pull door hinge block out through the front of the unit. Door hinge blocks are not reusable so be sure to use the replacement. **(C)**
4. Remove the magnetic pieces (2) with a screwdriver. Try not to lose the nut and washer on the back. Reinstall the pieces on the other side of the frame. **(D)**

**A****B****C****D**

**REVERSING THE DOOR**

1. Flip door 180 degrees so the rod hole is on the opposite side. **(A)**
2. Put the bottom floor panel back in. **(B)**
3. Slide rod into top hole and then bottom hole through the door hinge block. Close door to complete. **(C)**

**A****B****C**